

Common Issues & Temporary Fixes

Clogged Drain

Try using a plunger or a drain-safe cleaner. Avoid using harsh chemicals.

Tripped Breaker

Locate the breaker box and reset any tripped switches.

No Power in One Area

Check GFCI outlets and reset them if needed.

Toilet Won't Flush

Check the tank for chain or flapper issues. Avoid repeated flushing.

Heater Not Working

Ensure thermostat is set correctly and filters are clean.

Leaky Faucet

Place a bowl underneath to catch drips. Avoid using excessive force on handles.

Garbage Disposal Jammed

Press the reset button on the unit. Use a hex key underneath to unjam.